

SERIES 2480.0200 RASOFLEX – WHITE FILLER FOR WALLS
Uses

For filling and levelling purposes when walls are scraped or to eliminate non-homogeneous areas on plaster due to patches and use of different materials.

Suitable as connecting base.

Main features

White elastomeric paint for indoors and outdoors:

- high filling grade;
- elasticity;
- transpirability.

Technical features (data surveyed at 20°C)

Brookfield viscosity	cps	9000 ± 500
Specific gravity	kg/l	1.600 ± 0.100
Solids	%	78 ± 2
Film gloss	gloss	mat
Thinner	code	water
Dry to touch	minutes	30 - 60
Dry to recoat	hours	4 - 6
Theoretical spreading rate	sqm/l sqm/l	1.5 – 1.8 with a layer of 1.8 - 2 mm in thickness 5 - 4 with a layer of 0.3 – 0.4 mm in thickness

Methods of application

Spatula	thin with	water at 0 - 2%
Roll	thin with	water at 5 – 10%
After the application with a spatula or a float, wait some minutes then carve it with a rubber or expanded roll. The wetter the surface is the more rounded the drawing will be while if the product is dry, the carving will be rougher and sharper.		
Paint brush	thin with	water at 20 - 25%
Do not apply the product at lower a temperature than 5°C nor higher than +30°C nor with higher a relative humidity than 75% or with imminent rain. Wash brushes and tools immediately after use. Keep the product safe from frosting.		

Recommended painting cycles:
NEW, SEASONED, DRY AND CLEANED SURFACES

If the surface is grained and needs to be hardened, apply a layer of 2320.0100 Titalprimer (see Tech. Sheet) or 2340.0090 Silofix White (see Tech. Sheet) to ensure transpirability.

Then apply two layers of Rasoflex: the first thinned at 10-20% and the second at 5-10%.

If necessary, level the surface until you obtain a layer of 1-2 mm in thickness. Apply the product without thinning with a spatula.

The surface treated with Rasoflex can be coloured with Colormaker products.

PAINTED SURFACES

Remove old paint by scraping and brushing the surface. Then, apply Rasoflex as detailed above.

21/12/09